

GEOCHRON®

A timepiece. A masterpiece.™

IMPORTANT PACKING INSTRUCTIONS REGARDING YOUR GEOCHRON

When packing your GEOCHRON please follow these steps:

1. Set the date on the GEOCHRON to February 9th.
2. **LOCK THE MECHANISM SCREWS** (Located on the back, bottom middle section of the GEOCHRON.)
3. After locking the Mechanism Screws set the date on the GEOCHRON to March 21st.



4. Roll up the electrical cord and tape the cord to the bottom of the unit.
5. Tape an "X" across the Glass with painters masking tape.
6. Place the Geochron in a Poly Clear Bag, tape end closed.
7. Attach the 2 Inner End Foam Blocks and Inner Foam Flat Block as shown in the picture below.



8. Seal one end of the Inner Box with packing tape. Slide the Geochron into the Inner Box and seal open end of box with packing tape.



9. Attach the four outer foam corner blocks to the inner box as shown in the picture below.



OUTER FOAM CORNER BLOCKS

If your corner blocks do not look like this you will need to flip open the tab so that the block will fit over the box.



10. There are 4 Angle board pieces that go one in each corner of the Outer Box. Place those in the corners and then slide the Inner box into the GEOCHRON Outer box. Seal the open end of the Outer box securely with tape or staples.

