

IMPORTANT PACKING INSTRUCTIONS

Please follow these steps:

1. Set the date on the GEOCHRON to February 9th.
2. **LOCK THE MECHANISM SCREWS** (Located on the back, bottom middle section)
3. **After** locking the Mechanism Screws, set the date to March 21st.



4. Wrap the electrical cord and tape it to the bottom of the unit.
5. Tape an "X" across the glass with painters' masking tape.
6. Place the Geochron in the clear bag.
7. Hold the side foam blocks in place by using tape.



8. Depending on preference, the Geochron can be slid into the inner box by lying it on a flat surface, or it can be dropped into the opening with the box standing up.



9. Drop the inner box into the outer box, or lay both boxes on the floor and slide them together. Tape the return form to the inner box before closing the outer box flaps.

